



Abb.: Stromlaufplan
400V
KST 40

Fig: Circuit diagram
400V
KST 40

- 1 L1- Live / Phase.
- 2 L2- Live / Phase.
- 3 L3- Live / Phase.
- ⊕ PE – Earth / Erde.
- 5,6 T1,T2 – Door contact / Tuerkontakt.
- 7 P1 – Alarm contact / Alarmkontakt
- 8 P2 – Alarm contact / Alarmkontakt
- 9 P3 – Alarm contact / Alarmkontakt